


# BLAIR

PR



**E** Blanco Italia  
**EN** Italian White  
**FR** Blanc Cassé  
**DE** Italienisches Weiss  
**I** Bianco Italia  
**N** Wit



**E** Blanco Envejecido  
**EN** Aged White  
**FR** Blanc Vielli  
**DE** Weiß Veraltet  
**I** Bianco invecchiato  
**NL** Oude witte




**E** Decape Ocre  
**EN** Ochre Decape  
**FR** Ocre Decape  
**DE** Ocker Lasiert  
**I** Ocra Decape  
**NL** Oker Decape





**E** Decape Marrón  
**EN** Brown Decape  
**FR** Marron Decape  
**DE** Braun Lasiert  
**I** Marrone Decape  
**NL** Bruin Decape

















**E** Decape Gris  
**EN** Grey Decape  
**FR** Gris Decape  
**DE** Grau Lasiert  
**I** Grigio Decape  
**NL** Grijs Decape



**E** Oxido  
**EN** Rusty  
**FR** Oxié  
**DE** Rost  
**I** Ossido  
**NL** Roest



COD.															
PR-1030	<input type="radio"/> MSA-70	<input type="radio"/> PTX-20							KIT-4 o KIT-5			7-8	8435068960300	4	48
PR-1031	<input type="radio"/> MSA-70	<input type="radio"/> PTX-20	<input checked="" type="radio"/> PTE-22						KIT-4 o KIT-5			7-8	8435068960317	4	48
PR-1032	<input type="radio"/> MSA-70	<input type="radio"/> PTX-71	<input checked="" type="radio"/> PTX-72						KIT-4 o KIT-5			7-8	8435068960324	4	48
PR-1033	<input type="radio"/> MSA-70	<input type="radio"/> PTX-71	<input checked="" type="radio"/> PTX-73						KIT-4 o KIT-5			7-8	8435068960331	4	48
PR-1034	<input type="radio"/> MSA-70	<input type="radio"/> PTX-71	<input checked="" type="radio"/> PTX-74						KIT-4 o KIT-5			7-8	8435068960348	4	48
PR-1035	<input checked="" type="radio"/> MSA-60	<input checked="" type="radio"/> PTX-24	<input checked="" type="radio"/> PTE-28	<input type="radio"/> BR-01								7-8	8435068960355	4	48